## **TTHK** Double-Row Angular Contact Roller Rings RW



## Precautions on Use

### Precautions on Handling

- · Do not disassemble the Double-Row Angular Contact Roller Rings unit.
- · Dropping or hitting the Double-Row Angular Contact Roller Rings unit may damage it. Applying an impact force to the product could cause functional loss even if the product looks intact.

· Since each Double-Row Angular Contact Roller Rings unit contains high-quality lithium soap group grease No. 2 (THK AFB-LF Grease), you can start using the product without replenishing grease. However, the product requires regular lubrication since it has a smaller internal space than ordinary roller bearings and because the rollers need frequent lubrication due to their rolling

To replenish grease, it is necessary to provide a grease path that leads to the oil holes formed on the circumference of the outer ring. As for the lubrication interval, normally replenish grease of the same type while rotating the ring so that it is distributed throughout the interior of the bearing at least every six to twelve months even if the product rotates infrequently.

When the bearing is filled up with grease, the initial rotational torque temporarily increases due to the resistance of the grease. However, surplus grease will run out of the seals and the torque will return to the normal level in a short period.

- · Do not mix greases with different physical properties.
- · In locations exposed to constant vibrations or in special environments such as clean rooms, vacuum and low/high temperature, normal lubricants may not be used. Contact THK for details.
- $\cdot$  When planning to use a special lubricant, or use the product other than with grease lubrication, contact THK before use.

### Precautions on Use

- · Entrance of foreign material may cause functional loss. Prevent foreign material, such as dust or cutting chips, from entering the product.
- · Contact THK if you desire to use the product at a temperature above 80°C.
- · Avoid an environment where a coolant may penetrate into the Double-Row Angular Contact Roller Rings unit.
- · If foreign material adheres to the product, replenish the lubricant after cleaning the product with clean kerosene.
- · When using the product in locations exposed to constant vibrations or in special environments such as clean rooms, vacuum and low/high temperature, contact THK in advance.
- · The seal of the Double-Row Angular Contact Roller Rings unit is a dust seal, and cannot prevent the entrance of fine dust or liquid foreign material.
- The photo may differ slightly in appearance from the actual product.
- The appearance and specifications of the product are subject to change without notice. Contact THK before placing an order.

■ SWEDEN OFFICE

- Although great care has been taken in the production of this catalog, THK will not take any responsibility for damage resulting from typographical errors or omissions.
   For the export of our products or technologies and for the sale for exports, THK in principle complies with the foreign exchange law and the Foreign Exchange
- and Foreign Trade Control Law as well as other relevant laws.

For export of THK products as single items, contact THK in advance.

All rights reserved

# THK CO., LTD.

Head Office 3-11-6 Nishigotanda, Shinagawa-ku, Tokyo 141-8503 JAPAN International Sales Department Phone:+81-3-5434-0351 Fax:+81-3-5434-0353

## Global site: http://www.thk.com/

NORTH AMERICA	
THK America,Inc.	
•HEADQUARTERS	
Phone:+1-847-310-1111	Fax:+1-847-310-1271
OCHICAGO OFFICE	
Phone:+1-847-310-1111	Fax:+1-847-310-1182
NORTH EAST OFFICE	
Phone:+1-631-244-1565	Fax:+1-631-244-1565
●ATLANTA OFFICE	
Phone:+1-770-840-7990	Fax:+1-770-840-7897
●LOS ANGELES OFFICE	
Phone:+1-949-955-3145	Fax:+1-949-955-3149
SAN FRANCISCO OFFICE	
Phone:+1-925-455-8948	Fax:+1-925-455-8965
•DETROIT OFFICE	E 4 040 050 0455
Phone:+1-248-858-9330	Fax:+1-248-858-9455
Phone:+1-905-820-7800	Fax:+1-905-820-7811
	Fax:+1-905-820-7811
SOUTH AMERICA	
THK BRAZIL INDUSTRIA E	
Phone:+55-11-3767-0100	Fax:+55-11-3767-0101
EUROPE	
THK GmbH	
EUROPEAN HEADQUART	
Phone:+49-2102-7425-555	Fax:+49-2102-7425-556
<ul><li>DÜSSELDORF OFFICE</li></ul>	
Phone:+49-2102-7425-0	Fax:+49-2102-7425-299
<ul><li>STUTTGART OFFICE</li></ul>	
Phone:+49-7141-4988-500	Fax:+49-7141-4988-888
●U.K. OFFICE	
Phone:+44-1384-47-1550	Fax:+44-1384-47-1551
●ITALY OFFICE	

Phone:+39-02-9901-1801 Fax:+39-02-9901-1881

SWEDEN OFFICE	
Phone:+46-8-445-7630	Fax:+46-8-445-7639
<ul><li>AUSTRIA OFFICE</li></ul>	
Phone:+43-7229-51400	Fax:+43-7229-51400-79
SPAIN OFFICE	
Phone:+34-93-652-5740	Fax:+34-93-652-5746
●TURKEY OFFICE	
Phone:+90-216-362-4050	Fax:+90-216-569-7150
●PRAGUE OFFICE	
Phone:+420-2-41025-100	Fax:+420-2-41025-199
●MOSCOW OFFICE	
Phone:+7-495-649-80-47	Fax:+7-495-649-80-44
THK Europe B.V.	
●EINDHOVEN OFFICE	
Phone:+31-040-290-9500	Fax:+31-040-290-9599
THK France S.A.S.	
●PARIS OFFICE	
Phone:+33-1-7425-3800	Fax:+33-1-7425-3799
CHINA	
THK (CHINA) CO.,LTD.	
●HEADQUARTERS	
Phone:+86-411-8733-7111	Fax:+86-411-8733-7000
●SHANGHAI OFFICE	
Phone:+86-21-6219-3000	Fax:+86-21-6219-9890
●BEIJING OFFICE	
Phone:+86-10-8441-7277	Fax:+86-10-6590-3557
●CHENGDU OFFICE	
Phone:+86-28-8526-8025	Fax:+86-28-8525-6357
<ul><li>GUANGZHOU OFFICE</li></ul>	
Phone:+86-20-8523-8418	Fax:+86-20-3801-0456
SHENZHEN OFFICE	

Phone:+86-755-2642-9587 Fax:+86-755-2642-9604

	•XIAN OFFICE	_
	Phone:+86-29-8834-1712 THK (SHANGHAI) CO.,LTD.	Fax:+86-29-8834-1710
)	Phone:+86-21-6275-5280	Fax:+86-21-6219-9890
	TAIWAN	
	THK TAIWAN CO.,LTD.  ●TAIPEI HEAD OFFICE	
	Phone:+886-2-2888-3818  TAICHUNG OFFICE	Fax:+886-2-2888-3819
	Phone:+886-4-2359-1505 ●TAINAN OFFICE	Fax:+886-4-2359-1506
	Phone:+886-6-289-7668	Fax:+886-6-289-7669
	KOREA	
	SEOUL REPRESENTATIVE	
	Phone:+82-2-3468-4351	Fax:+82-2-3468-4353
	SINGAPORE	
	THK LM System Pte. Ltd.	E 05 0004 5550
	Phone:+65-6884-5500	Fax:+65-6884-5550
	THAILAND	LTD LM Contain Division
	THK RHYTHM(THAILAND) CO.  Bangkok Branch	., LTD. LIVI System DIVISION
)	Phone:+66-2751-3001	Fax:+66-2751-3003
	INDIA	
	THK India Pvt. Ltd.	

●HEADQUARTERS & Bangalore Branch

Phone:+91-80-2340-9934 Fax:+91-80-2340-9937

Pune Branch

Phone:+91-20-4120-8742

Chennai Branch

Phone:+91-44-4042-3132 Ahmedabad Branch Phone:+91-79-6134-4444